



## Cable Cover and Mounting Plate Installation Guide

### Room Placement

The UNITY Cable cover and Mounting Plate can be used in almost any UNITY installation scenario:

- A. Surface Wall Mount.
- B. Placed on a shelf, horizontally, or vertically with the Flex Stand.
- C. Mounted to a tray behind an interactive display.
- D. In combination with the Wall Mount Bracket.

**NOTE:** If wall-mounting vertically, ensure the buttons will be upright when you slide the UNITY onto the tray. If you need to rotate the buttons due to room conditions forcing placement location, contact Customer Care at Boxlight for instructions.



### Installation

- If Wall Mounting:** Use the metal plate as a template (paper template available online). Ensure the plate is level.
- Secure the metal plate to the wall with the included #8 1.5" screws, using the plastic anchors if needed.
- Cables can be pulled through the opening in the back of the metal plate, or routed through the back of the plastic cover.
- Slide the UNITY onto the metal plate, aligning the 4 metal tabs with the slots on the back of the UNITY.

**TIP:** If necessary to ensure a tighter fit, use needle-nose pliers to bend up the center tab slightly so that more spring tension is applied when the UNITY snaps into place. The UNITY should not slide when simply inserting or removing a cable. It should require some reasonable force to be removed from the tray.

- Place the cable cover on the back. Use the included small M2x8 screws to secure the cover to the tabs on the metal plate (optional) to prevent tampering.

