

# robo E4

## Unboxing Guide



1. Open the box and remove the Styrofoam.
2. Take out the spare build plates and postcards. **Save these postcards as they provide access to an online training course and curriculum resources!**



3. Open the plastic wrap and remove the printer from the box. There are handles on the bottom edge.



4. Remove the clear wrapping and tape.



5. Remove the top foam.

6. Collect the filament spool and power cord.



7. Remove the foam from inside the top and front of the printer. Remove the box with tools.

8. **Unscrew the four screws securing the build plate.** There are instructions in the printer on where they are located.



9. Use an Allen wrench to attach the spool holder to the back of the printer. It can be found in the box with the tools.



10. Plug in the power cord. Move the power button to an “on” position.

11. Press the power button on the front to turn on your 3D printer.



How-to videos are available on the MimioSTEM YouTube page. Scan the QR code to the right.