

Note: this procedure applies only to ProColor panels that have already installed the firmware update released in August 2022, in which Opera replaces Chrome as the default browser.

1. Press the **Apps Waffle** on the **Home Screen** to view all installed apps .



2. Launch the **Cleverstore** app.



3. Create a Cleverstore account, or **Sign In**. This button will open a web page where you can enter a username and password. **Agree** to the terms and conditions.



4. Press the **Search** icon at the top right and type "Chrome".



5. Tap on **Google Chrome**.



## Google Chrome

Google Chrome is a fast, easy to use, and secure web browser.





## Google Chrome

Google Chrome is a fast, easy to use, and secure web browser.

OVERVIEW

SCREENSHOTS

REVIEWS

EDITIONS & PRICING

6. From the Chrome page, choose the option on the right for **Editions & Pricing**.

7. Press **Try Now** to open the subscription page.

8. Click **Next** to advance through the purchase screen. All apps on Cleverstore are free, so you will not be charged.

9. When complete, press **Go To My Apps** to view all the available apps in your account.

10. Find **Chrome** in the list of **My Apps** and press the icon to begin downloading. This process will take some time.

11. Follow the prompts to **Stage** and **Install** the app. When complete, you will see a checkmark confirming the installation.

12. After installation is complete, you will find **Chrome** in the **Apps Waffle**.

TRY NOW

Due 08/31/22

\$0.00

By placing your order you agree to our [Privacy Policy](#) and [Terms of Service](#)

NEXT

GO TO MY APPS



Google Chrome

● DOWNLOAD



App installed.

